Hammerhead boring device

Technical details :

- Thanks to narrow design of back part, suitable for every box column drill
- Permanently mountable
- Adjustable continuously to the right/ to the left and to the front and back
- The drilling angle and the bevel of the shaft are easily adjustable with scale gradations
- Block for adjusting the length of drilling

Instructions

A: plate for fixing the machine to the box column drill

B: screw to adjust the machine to the box column drill right/left

C: screw to adjust the machine to the box column drill to the front/back

D: set screw for clamping the hammerhead

NEW: with quick release

E: lever to adjust the bevel of the shaft

F: scale for bevel of shaft

G: adjusting screw to adjust the drilling angle

H: scale for drilling angle

I: block for hammerhead

Scale schedule (Gon) according to Renner goniometer for hammerheads article no. 431605

