JAHN
PIANOTEILE

USER'S MANUAL

● ASSEMBLY METHOD ON THE BACK

■ ASSIST STOOL ASS-V

Release the locked latches on both sides of the assist stool and lift the top plate up. 4 height adjusters are stored inside.




Latch



※To adjust the height: There are 5 levels, including the thickness of the wooden plate plus the height adjusters.

Height adjuster



1st.. level H:app2.5cm



▲① Pull the 4 non-slip rubber pads out from the corners of the bottom plate.

(Thumbtacks are attached to the backs of the rubber pads.)



▲② Attach the non-slip rubber pads to the 4 inside corners of the bottom plate.




▲ Place the bottom plate upside down to complete the 1st. level. (Note: the bottom plate has to be placed upside down.)

2nd. level H:app 5cm



▲ You can use the stool in its pre-assembled form.

3rd. level H:app 7.5cm



◂ Insert the height adjusters into the holes and align them so that they are parallel to the outer lines. (picture left)


Fit the top plate onto the adjusters ▸





▲ Rotate the 4 height adjusters by 90 degrees to finish.

4th. level H:app 10cm




◂ Insert the height adjusters into the holes and align them so that they are parallel to the inner lines. (picture left)



▲ After fitting the top plate to the adjusters, rotate the 4 adjusters 90 degrees to fix them.

5th. level H:app 12.5cm



◂ Insert the height adjusters into the holes and align them so that they are parallel to the inner lines. (picture left)



▲ After fitting the top plate to the adjusters, rotate the 4 adjusters 90 degrees to fix them.

● Precautions when using

- ○Please take care when using the Stool. If some rough surfaces remain around the edges of the wooden plate, they may cause injuries.
- ○When you need to carry the Stool, you must place the latches in the "lock" positions. Otherwise, it may cause damage to floors or get caught on something.
- ○Please do not stand on the Stool or use it as a step-ladder. You may risk injury.
- ○We ask for your kind understanding should there be any slight differences in Stool sizes.

● Assist Stool: Maintenance

- ○Please always keep the Assist Stool clean using a neutral detergent. Take special care to keep the non-slip rubber pads clean. When they becomes dirty, the stool can easily slip.
- ○ If the height adjuster's dowels are damaged, please unscrew them and contact the shop you bought the Assist Stool from. We can exchange them for new ones.